



Offset and Gain Adjustments to Analog Inputs, see last page of this pdf file, top of page.

## 4. CONFIGURATION

Press  ("Menu"), then the **"More"** soft button to enter Configuration mode. A vertical list appears with a provision to configure Channel, Tools, Message, Display, Instrument, Security, Auto-Output, Demo, and system Information. In addition, the Save, Load, Default and Home soft buttons also appear.



### Soft buttons



Enter key



Up directional key



Down directional key



Home key

Various options are available to enter into configuration mode

Option-1: Select the mode by pressing up & down directional keys, then press **"Enter"** key

Option-2: Select the required mode directly with a touch, then press **"Enter"** key

Option-3: Select the required mode by pressing the mode two times quickly, it is same as a double click from a mouse

**Save:** Save configuration from the recorder to a USB Stick or an SD Card.


**To read the configuration from a USB Stick for the first time or any time the configuration has been changed, it is important to press the “Save” soft button to save configuration changes to the USB Stick or SD Card beforehand.**

**Load:** Load configuration from a USB stick or SD Card to the recorder.

**Default:** If the configuration is set incorrectly, “Default” is a useful key to recall the default settings for the analog input card inserted into rear expansion slot.

**Home:** Returns the User to the home page.

## 4.1 Channel


Path:  (Menu)-More-Config-Channel

AI  
DI  
Math  
AO  
DO  
External

This section is to configure different type of channels. Analog Input (AI), Digital Input (DI), Math, Analog Output (AO), Digital Output and External device channels.

### 4.1.1 Analog Input

After entering the Configuration mode, in “Channel”, select “AI”, then Press the “Enter” key to get into Analog Input Channel mode. It displays the Analog input **AI1** as the first analog input channel configuration page. Press directional keys < > at the bottom to select other channels. Press directional keys ↑ ↓ on the right hand side to select the column. **After completing Configuration, press “Back” soft button, then press “Home” soft button to return to main display. All configurations will be saved automatically.**



**Copy:** For example, to copy the channel configuration from channel 1 to channel 2, select the source channel, in this case AI1 (or whatever the channel is named), press on “Copy” button. Now, a “Paste” button will get enabled, go to target channel, say channel 2, and then press on “Paste” button.

**Name:** Enables the User to define the name for each channel with a maximum of 18 characters.

Select “Name”, then Press “**Enter**”, soft button, a keyboard with several keys appear. Press “**Shift**” to select special characters. Press “**Caps**” to select capital letters. Press soft key “**OK**” after entering a new channel name.

**Desc:** The description about a specific channel on the display.

**Type:** Option available to enable or disable the channel from selection

**Filter:** It is to reduce the noise of input signal before sampling. It is possible to select range from 1 to 16 sec. It is a soft filter available to reduce fast variation of analog inputs. It gives a moving average value. For example, if the filter value is set as 5 sec for AI1, it means all the samples collected in the last 5 sec shall be averaged, and the value is available to record as per Log method.

**Log:**

**Data Type:** 2 byte

2 byte range: -32767 to +32767

**Trigger:** Two options are available

- a) Disable: Select disable while the recording of a specific channel is not required at this time
- b) Enable: Select Enable while the recording of a specific channel is required at this time

**Method:** This is the method of logging measured data. Select the column and press “enter”. Then choose the Log method of Instant, Average, Minimum or Maximum data.

**Instant:** logging the last measured data at the sampling interval

**Average:** logging the averaged measured data at the sampling interval


**Minimum:** logging the minimum measured data at the sampling interval

**Maximum:** logging the maximum measured data at the sampling interval

**Speed:** It is the logging speed (recording speed) of measured data. Select Log Speed column, then choose one of the following

100ms/Dot  
1 Sec/Dot  
2 Sec/Dot  
5 Sec/Dot  
10 Sec/Dot  
20 Sec/Dot  
30 Sec/Dot  
1 Min/Dot  
2 Min/Dot

(Auto)Set Jobs under Events




### Sensor

Type: Thermocouple K Type, °C

Unit: °C

Range: -200.0~1370.0

**Type:** Select the sensor input type for the Channel.



RTD JPT100 Type

RTD RTD1 Type

Milli-Volts

Volts

Current

**Unit:** The engineering unit of input.

**Range:** Select based on Sensor type

Select
-200.0~1370.0
-200~1370
<b>200.0~1370.0</b>

Sensor	Select
Type: Milli-Volts	0~1000
Unit: mV	0~60
Range: 0~1000	<b>0~1000</b>
	-60~60

Sensor	Select
Type: Volts	0~5
Unit: V	0~10
Range: 0~5	<b>0~5</b>
	1~5
	-2~2
	-20~20

Sensor	Select
Type: Current	4~20
Unit: mA	0~20
Range: 4~20	<b>4~20</b>
	-20~20

**Scale:** Appears only for linear inputs Ex: mV, Voltage, current etc..

Scale  
 Unit: °C  
 Low: -120.0  
 High: 1000.0

**Offset:** It is offset value to correct the sensor error.

**Gain:** It is a multiplier to correct the sensor error.  
 The correct value = (the process value x gain) + offset

## Events

Events are frequently used for Alarm purposes. Events can also be used for digital outputs (DO), Timer, Totalizer, Counter or Report.

Maximum five events are possible to set for each Analog Input

Press "Add" to add new event

Press "Remove" to remove selected event

Events  
 Add  
 Remove  
 1  
 Type: H  
 SetPoint: 776.0  
 Log: Log Alarm  
 Job1: No Action  
 Job2: No Action  
 Hysteresis: 0.0

Type: There are various types of H, L, HH, LL, Dev+, Dev-, and Error to be selected for a job

or Alarm purpose

**H:** High limit. When the process is over high limit, the alarm or job is actuated.

**L:** Low limit. Any the process is lower than low limit, the alarm or job is actuated

**HH:** High high limit, to set up another limit higher than high limit for double warning.